

Affected Product Generation

SonicWALL Gen 4 Appliances (Gen 5 Appliances are not affected)

Affected Products

SonicWALL Gen 4 Appliances consisting of

- TZ 150
- TZ 150W
- TZ 170
- TZ 170W
- TZ 170 SP
- TZ 170SPW
- TZ 180
- TZ 180W
- TZ 190
- TZ 190W
- PRO 1260
- PRO 2040
- PRO 3060
- PRO 4060
- PRO 5060C
- PRO 5060F

Affected Firmware Versions:

All SonicOS Enhanced firmware versions prior to 3.4.1.0-2e for models

- TZ 170
- TZ 170W
- TZ 170SP
- TZ 170SPW
- PRO 1260

All SonicOS Enhanced firmware versions prior to 4.0.3.4.12e for models

Related Information

North America Support:
+1 888.777.1476

International Support:
[Contact](#)

- TZ 180
- TZ 180W
- TZ 190
- TZ 190W

All SonicOS Enhanced firmware versions prior to 4.2.0.0-10e for models

- PRO 2040
- PRO 3060
- PRO 4060
- PRO 5060C
- PRO 5060F

All SonicOS Standard firmware versions prior to 3.1.6.3-4s for models

- TZ 150
- TX 150W
- TZ 170
- TZ 170W
- TZ 170SP
- TZ 170SPW
- PRO 1260
- PRO 2040
- PRO 3060

All SonicOS Standard firmware versions prior to 3.9.1.2-50s for models

- TZ 180
- TZ 180W

Issue Summary

A vulnerability was discovered that allows potential remote attackers to leave a malicious log entry which affects the log parsing functionality in some versions of SonicOS. An attacker can leave log entries with format string metacharacters, which when viewed by an administrator in affected versions of SonicOS, can cause a log task malfunction and a subsequent defensive reboot by SonicOS watchdog diagnostics

Resolution Summary:

Hot Fix firmware versions for the vulnerability can be downloaded from www.mysonicwall.com The hot fix versions are

SonicOS Enhanced firmware version 3.4.1.0-2e for models

- TZ 170
- TZ 170W
- TZ 170SP
- TZ 170SPW
- PRO 1260

SonicOS Enhanced firmware version 4.0.3.4.12e for models

- TZ 180
- TZ 180W
- TZ 190
- TZ 190W

SonicOS Enhanced firmware version 4.2.0.0-10e for models

- PRO 2060
- PRO 3060
- PRO 4060
- PRO 5060C
- PRO 5060F

SonicOS Standard firmware version 3.1.6.3-4s for models

- TZ 150
- TX 150W
- TZ 170
- TZ 170W
- TZ 170SP
- TZ 170SPW
- PRO 1260
- PRO 2040
- PRO 3060

SonicOS Standard firmware version 3.9.1.2-50s for models

- TZ 180
- TZ 180W

More Information

For more information about this Service Bulletin, please contact SonicWALL Global Support Services.

<http://www.sonicwall.com/us/support/contact.html>

You are receiving this message because you indicated that you were interested in information about SonicWALL Internet security solutions. If you no longer wish to receive future messages and offers from SonicWALL, you can unsubscribe at the following link

[Click here to unsubscribe](#)

If you do not want to receive any future communication from SonicWALL, you may remove your e-mail address from our list by going to the following link

[Click here to be removed from all e-mail lists](#)